

# Samsung Galaxy S7 and S7 edge

## Maintaining Water and Dust Protection

### What is an IP rating and what does it mean for your Samsung Galaxy S7/S7 edge:

An IP (Ingress Protection) rating is an international standard that shows you the level of ingress protection of your Samsung Galaxy S7/S7 edge. The Samsung Galaxy S7 and S7 edge devices have been certified to an IP68 rating. The Samsung Galaxy S7 and S7 edge are built to do more, in more places. With an IP68 rating, they're water resistant to a maximum depth of 1.5m for up to 30 minutes, and are protected from dust, dirt and sand - all without the need for extra caps or covers. Now there's less to worry about. You can enjoy more freedom to explore, stay connected, and capture the adventure.

### How to properly care for and use your Samsung Galaxy S7/S7 edge:

The Samsung Galaxy S7/S7 edge may be damaged if water or dust enters the device. Follow these tips carefully to prevent damage to the device and to help maintain the water and dust-resistant performance of the Samsung Galaxy S7/S7 edge.

- Do not immerse the Samsung Galaxy S7/S7 edge in water deeper than 1.5 metres and do not keep it submerged in water less than 1.5 metres deep for more than 30 minutes.
- Do not expose the Samsung Galaxy S7/S7 edge to water moving with force, such as water running from a tap, ocean waves, or waterfalls.
- If the Samsung Galaxy S7/S7 edge is exposed to freshwater, dry it thoroughly with a clean, soft cloth. If the Samsung Galaxy S7/S7 edge is exposed to any liquid other than freshwater, gently rinse the device with still fresh water immediately and dry it thoroughly with a clean soft cloth. Failure to gently rinse the device in still fresh water and dry it as instructed may cause Samsung Galaxy S7/S7 edge to suffer from operability or cosmetic issues.
- If the Samsung Galaxy S7/S7 edge is dropped or receives an impact, the water and dust-resistant features of the device may be damaged.
- The touch screen and other features may not work properly while the Samsung Galaxy S7/S7 edge is in water.

The Samsung Galaxy S7/S7 edge has been tested in a controlled environment and certified to be protected against water and dust ingress in specific situations (meets requirements of Classification IP68 as described by the International Standard IEC 60529 – Degrees of Protection provided by Enclosures [IP Code]; test conditions: 15-35oC, 86 – 106kPa, 1.5 metres, 30 minutes).

Please follow the instructions outlined above to maintain the water and dust resistant performance of your Samsung Galaxy S7/S7 edge.

# Samsung Gear S2

## Maintaining Water and Dust Protection

### What is an IP rating and what does it mean for your Samsung Gear S2/ Gear S2 Classic:

An IP (Ingress Protection) rating is an international standard that shows you the level of ingress protection of your Gear S2/ Gear S2 Classic. The Samsung Gear S2 /Gear S2 Classic devices have all been certified to an IP68 Rating which means that these devices are protected against water ingress to a maximum depth of 1.5 metres of water for up to 30 minutes, as well as protected against dust ingress.

### How to properly care for and use your Samsung Gear S2/ Gear S2 Classic:

The Gear S2/ Gear S2 Classic may be damaged if water or dust enters the device. Follow these tips carefully to prevent damage to the device and to help maintain the water and dust-resistant performance of the Gear S2/Gear S2 Classic.

- Do not immerse the Gear S2/ Gear S2 Classic in water deeper than 1.5 metres and do not keep it submerged in water less than 1.5 metres deep for more than 30 minutes.
- Do not expose the Gear S2 /Gear S2 Classic to water moving with force, such as water running from a tap, ocean waves, or waterfalls.
- If the Gear S2 /Gear S2 Classic is exposed to freshwater, dry it thoroughly with a clean, soft cloth. If the Gear S2/ Gear S2 Classic is exposed to any liquid other than freshwater, gently rinse the device with still fresh water immediately and dry it thoroughly with a clean soft cloth. Failure to gently rinse the device in still fresh water and dry it as instructed may cause the Gear S2 /Gear S2 Classic to suffer from operability or cosmetic issues.
- If the Gear S2 / Gear S2 Classic is dropped or receives an impact, the water and dust-resistant features of the device may be damaged.
- The touch screen and other features may not work properly while the Gear S2/Gear S2 Classic is in water.

The Samsung Gear S2/ Gear S2 Classic has been tested in a controlled environment and certified to be protected against water and dust ingress in specific situations (meets requirements of Classification IP68 as described by the International Standard IEC 60529 – Degrees of Protection provided by Enclosures [IP Code]; test conditions: 15-35oC, 86 – 106kPa, 1.5 metres, 30 minutes).

Please follow the instructions outlined above to maintain the water and dust resistant performance of your Samsung Gear S2/ Gear S2 Classic.